



BOLEX INSTRUCTIONS

The Norris Single Frame Motor mounts on the Bolex Rex 4, Rex 5, and SBM Cameras. With a special bracket it can be mounted on the EBM camera. Power required is 12 to 24 VDC.

Important: The camera spring must be disengaged by locking the motor lever down to "0" position, and by locking the camera trigger back to the "M" position.

Remove the camera wind handle by turning in a clockwise direction and unscrew from camera.

Motor is mounted on the 1 to 1 drive shaft. There are four screws on the motor that screw into the four threaded accessory locations.

Before mounting the motor, power it up and fire at least one frame too be sure it is in the start position.

The shutter should be moved to cover the aperture with the 1 to 1 drive pin set at one and seven o'clock. The shutter should always cove the aperture at the start and after each frame.